

Receipt Printer



Receipt Printers Set up

Step 1. Power on printer by plugging in the power cord.

Receipt Printer Connection with USB

Step 2. Once the printer is powered on you will connect the USB Type A to the AMP Bridge and the USB Type B port located on the back of the printer. Devices connected by USB will be automatically added to the available printers list.

Step 3. When the receipt printer is configured, a cash drawer must be attached. Receipt printers will have an access point labelled for **Cash Drawers**. See Figure 2.



Figure 2. Printer with port for Power, Cash Drawer (Labelled DK) and USB Connection to POS Bridge Station.

Port 1. Power Supply

Port 2. Cash Drawer

Port 3. USB Type B.

Corresponds to port C in Figure 1

Port 4. Ethernet port